




Servo Electric Tapping Machine

M16E/M30E/M36E

Operation Manual



Contact Number : 8895929247/9831029247

Catalog

Safety instructions	2
Purpose and specification	3
Installation instructions	5
Installation and use diagram of optional components	6
Installation of upper and lower lifting screw assemblies	8
Use of vertical and horizontal tapping components	8
Use of jet and injection components	8
Working range of tapping machine	9
quick start guide	10
Tapping mode operation instructions	12
Operating instructions for screwing mode	16
Injection setting, injection setting	18
Common faults of touch control system	20
Routine maintenance and repair	21
Comparison table of common tap parameters	22
Part index drawing of tapping machine	23
warranty card	26

OUR LOCATIONS

H & O SHOWROOM

116,117,G.T. ROAD, SALKIA
HOWRAH- 711 106

BOMBAY ROAD WORKS

NH-6 (BOMBAY RD),
P.O.- ARGORI, HOWRAH- 711 302

DELHI ROAD WORKS(MANUFACTURING UNIT)

DURGAPUR EXPRESSWAY,
VILL- GOYE, PS- DADPUR PO- DANPUR
HOOGHLY- 712 305

ODISHA WORKS

Plot No. 133,Phase-1,New
Industrial Estate, Cutback-754021,Odisha

PUNJAB (MANUFACTURING UNIT)

G.T. Road,Dhandari, Kalan,
Punjab-141010

KOLKATA SHOWROOM

71, GANESH CHANDRA AVENUE
CHADNI CHOWK, KOLKATA- 700013,
WEST BENGAL

SAFETY

- That working table or mounting surface must be lagged to the floor and secure before installation.
 - Children not easy to touch machine.
 - Not exposed in the Dust Flammable and explosive environment.
 - Always secure the work piece to the table before operating the machine!
- Wear safety glasses when operating this tapping machine.
 - Do not wear jewelry or loose clothing when operating.
 - Tie hair back before operating machine.
 - Do not wear gloves when operating this equipment.
 - Keep hands clear of the motor chuck and tap when actuating the motor.
- Do not alter or modify the motor or tapping unit by yourself.
 - Keep hands free of pinch points on the tapping unit when operating.
 - When any hazard is detected, turn the power switch off to stop the spindle rotation and feed.

Maintenance

Perform regular maintenance according to the manual, Periodically inspect for damage, loose hardware or anything irregular. Keep both the motor and chuck free from contamination by cleaning regularly:

SPECIFICATION

This machine is designed for tapping, Tightening, and light reaming of holes.

Model	M16E	M30E	M36E
Type	Electric threading machine	Electric threading machine	Electric threading machine
Voltage	220V50Hz	220V50Hz	220V50Hz
Power	600W	1200W	1200W
Tapping range	M3-M16	M6-M30	M6-M36
Connector	GT12-T14	GT24-T20	GT24-T20
Collet	M3-M16	M6-M24	M6-M36
Quantity	8只	8只	11只
Operation mode	Vertical, vertical and horizontal*	Vertical, vertical and horizontal*	Vertical, vertical and horizontal*
Working radius	1045mm、1545mm*	1180mm、1735mm*	1180mm、1735mm*
Minimum radius	330mm	370mm	370mm
Maximum speed	375rpm	200rpm	125rpm
Customized	Customizable	Customizable	Customizable
Weight	30KG	53KG	56KG

► Standard components


List	Quantity
Tapping machine main body	One pc
Base Mount	One pc
Power cord	One pc
Allen Key	One pc
Tap holder	One set
Wrench for Tap holder adjust	One pc

► Optional accessories


List	Quantity
Magnetic Chuck 300kg	One pc
Magnetic Chuck 600kg	One pc
Magnetic Chuck 1000kg	One pc
Working table 900*600mm	One pc
Working table 800*500mm	One pc
Lifting screw	One pc
Long range tapping arm	One pc

INSTALLATION


1. Use Four M10 bolts to fix Base Mount, if not with our working table drill and tap 4 bolt holes on a flat smooth table or work bench. (See base Mount diagram as below)
2. Secure the base mount and fix the positioning nuts at the suitable height
3. Slide the Control unit Mount onto the shaft of the base mount
4. Tighten the shaft cover



Optional Component Installation



Optional Component Installation



Lifting screw assemble (Optional)

1. Inserting Lifting screw into hole on the arm, turn hand wheel to adjust positioning nut at desired height (Positioning Nut prohibited to take out)
2. Make Solide base to meet the Axis
3. Tighten the nut and washer in the top of Axis, make sure machine go up and down smoothly

Universal Tapping Head Operation (Optional)

To make sure tapping head sound perpendicular to the work surface

Loosen the Locking nut to adjust the position of the tapping head between vertical and horizontal tapping.


Before tapping, make sure Locking Nut is tightly fixed aligned to the workpiece

When returning the head to the vertical tapping position, remember that locking nut tightly fixed.

Use Of Auxiliary Components For Air Injection And Fuel Injection *

1. As shown in Figure 4, find the connection port of the air pressure source at the bottom and insert an 8mm air pressure pipe. It is recommended that the gas supply source be treated by the oil-water separator to ensure the normal service life of the jet and injection components.
2. As shown in Figure 5, the compressed air throttle valve has a single function of air injection. Turn the flow adjusting knob to adjust the amount of air blowing.
3. As shown in Figure 6, the oil air mixing spray has the function of fuel injection and jet mixing. Turn the oil mist adjusting knob to adjust the amount of fuel injection, and turn the air adjusting knob to adjust the amount of air blowing.

WOKING RANGE



OPERATION

Pls note, always wear safety glasses and use proper safety precautions when operating tapping. Gloves are not recommended when operating this machine

Connect the machine to a grounded 220V 50/60HZ electric supply
The circuit is protected with a circuit breaker as Photo 5, when power fault
Circuit breaker should be checked

CAUTION:When making repairs to this unit, always disconnect the main power supply




Photo 8




Photo 9

Insert Taps

Select the correct tap holder for the tap size required, insert the tap into the holder by depressing the locking ring, seat the top square into the tap holder, release the locking ring.

We have ISO/DIN/JIS/ANSI tap holder to meet various country standard.

Insert Tapp holder

1. Push up on the collar of the quick change chuck before inserting the tap holder, insert the tap holder into the "quickly change chuck". Turn the holder until the "ears" of the holder locate the slots of the chuck, push up to lock the holder into position. To change holder, release the tap holder by pushing up on the collar of quick change chuck.




Photo 10




Photo 11

Power ON/OFF

- ▶ As shown in Figure 11, press the power switch button on the machine, the indicator light will be on, and the machine is in the ON state.
- ▶ When the button is pressed, the indicator light will go out, and the control panel will have a delay picture of several seconds after the machine is shut down, which is normal.




Photo 12




Photo 13

Tapping Operation

- ▶ As shown in Figure 12, refer to the instructions on the next page to correctly set the thread specification, tapping depth and tapping speed.
- ▶ As shown in Figure 13, press and hold the "Feed" button on the handle to conduct manual tapping operation, and press the "Back" button to conduct threading operation. After clicking the "Auto" switch mode, click the "Feed" button to conduct automatic tapping, and click the "Back" button to stop tapping.

EXERT ONLY ENOUGH DOWNLOAC PRESSURE TO STARTTHE
 The tap will engage itself and follow the hole, when tapping a through hole remember that the tap will protrude on the bottom side of the workpiece, make sure sufficient clearance below the workpiece to allow tap to break through and not hit the work surface. Our tap holder with torque clutch, that will ratchet and stop the tap from turning when tap reach the bottom of hole.

Thread	Thread pitch	Work mode
<input type="text"/>	<input type="text"/> mm	<input type="text"/>
Feed speed	Torque	Tapping Depth
<input type="text"/> rpm	<input type="text"/> N.m	<input type="text"/> mm
Rollback speed	Counter	<input type="text"/>
<input type="text"/> rpm	<input type="text"/>	<input type="text"/>
User parameter	<input type="text"/>	Deep hole operation
<input type="text"/>	<input type="text"/>	Ordinary operation

Ordinary Processing

- 1.Thread: Metric/Inch Thread available
- 2.Thread Pitch: When Thread confirmed, will create Standard Thread Pitch automatically, and you can also set at require
- 3.Work Mode
 Normal: suitable for small thread
 Smart: suitable for big thread, will automatic adjust speed at torque fluctuation
- 4.Feed speed: Forward tapping speed parameter
- 5.Rollback speed: Reverse tapping speed parameter
6. Torque: when Thread confirmed, will create Standard Torque Protection value, that workable just turn on"Torque Protection" Button
7. Counter: Counting tapped workpiece synchronization
8. Tapping depth: Tapping Depth paramter setup
- 9.Manual/Auto: Change over Manual/Automatic tapping

Thread	Thread pitch	Work mode
<input type="text"/>	<input type="text"/> mm	<input type="text"/>
Feed speed	Feed depth	Tapping Depth
<input type="text"/> rpm	<input type="text"/> mm	<input type="text"/> mm
Rollback speed	Rollback depth	<input type="text"/>
<input type="text"/> rpm	<input type="text"/> mm	<input type="text"/>
User parameter	<input type="text"/>	Deep hole operation
<input type="text"/>	<input type="text"/>	Ordinary operation

Deep hole tapping

Feed depth: parameters should less then tapping depth
 Rollback depth: parameters should less then feed depth
 Other parameter refer to ordinary tapping

Workpiece Select 1				
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
1	2	3	4	5
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
6	7	8	9	10
Page up		Page down		Back

Workpiece saving for involking

Machine can restore 20 workpiece parameter for next directly application

Hole bottom delay time [] s	Direction []	Mode selection	
No-load torque [] N.m	Retreat more laps []	Restore settings	
Torque protection []	Real-time data []	Intelligent detection	
User parameter	Machine parameter	Deep hole operation	Ordinary operation

User parameters

- 1.Hole bottom delay time: when tap to set depth, tap delay time range 0-10s
2. Direction: Motor rotation in clockwise or anticlockwise
3. No-load torque (Details refer to next page)
- 4.Retreat more taps: To ensure reverse smoothly, reverse circles more than forward circles
- 3.Torque protection: Preset standard break torque limits to protect taps
- 5.Retreat more taps
6. Real-time data: turn on,tapping process will be displayed synchronization
7. Mode selection Tapping & Tightening Mold
8. Restore settings: CAUSIOUS restore factory settings
9. Intelligent detection. (Details refer to next page)
- 10.Machine parameters: always not allowed to revise.

Test troque []	No-load torque []	Load data
Test status []	[]	
1.Press the"start test"button,and the motor starts running at the maximum speed. After 16 seconds, the motor stops running OK, display test torque in the test torque bar, click"load data" to testenter the test torque value into the no-load torque field.		
		Back

No-loaded Torque

Click "start test" button, motor rotate at maximum speed, and stop in 16seconds, will show test result, click " load data", data will be added to no-loaded torque, then back.

When in tapping process, always torque protection value low popups then you can add no-loaded torque base on 0.1 until no popups

Forward signal []	Reverse signal []	Processing data	
A、B、Z	U、V、W	Trouble shooting	
[]	[]		
1. Press forward button,forward signal display on, press reverse button,reverse signal display on. 2. Manually turn the tapping chuck, A、 B and Z will display data in 0-2000 direct cycle,U、 V、 W display random Numbers 1-6.			
User parameter	Intelligent detection	Deep hole operation	Ordinary operation

Interligient detection

Depressing forward BUTTON, function is "Work", if not button or line fault
 Depressing Reverse BUTTON, function is "Work", if not button or line fault
A B Z Test, Hand Rotate the tap holder, function is data range "0-2000, if not or exceed, encoder fault
u v w test, Hand Rotate the tap holder, function is data range "1-6", if not or exceed, encoder fault
 Working: will record tapping data such as speed, depth, Torque

Troubleshooting

Tigthening operation

1st bolt MAT.	1st bolt size	1st speed/rpm	1st torque/N.m
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
1st back/degree	Back speed/rpm	Counter	2nd back/degree
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
2nd bolt MAT.	2nd bolt size	2nd speed/rpm	2nd torque/N.m
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
User parameter	Machine parameter	AUTO	Tighten operation

Nut materiasl: Choose Nut materials
Nut size: choose Nut thread
Tighening speed: Set tighening speed

1. Torque Set: will auto generate torque value
2. Reverse angle: Spindle reverse angle
3. Reverse speed Spindle rotation speed
4. Counting: counting finished workpiece
5. Auto/Manual

Acceleration	Direction	Mode selection
<input type="text"/>	<input type="text"/>	
Torque holding time	Torque integral	Restore Settings
<input type="text"/>	<input type="text"/>	
Torque constant	Torque coefficient	<input type="text"/>
<input type="text"/>	<input type="text"/>	
User parameter	Machine parameter	Factory parameter
		Tighten operation

User parameters

1. Acceleration: Controll machine accelerated speed, small value. acceleration slow
2. Direction: Machine tapping direction clockwise or anticlockwise
3. After Spindle rotation pausing, lock Axis time
4. 80 not allowed to change
5. 2 not allowed to change

Torque ratio coefficient: correct the output torque value. When the actual output of screwing torque is greater than the set value, fine-tune the coefficient in 0.01 increments, such as 0.36, 0.37, 0.3... otherwise, it will gradually decrease, such as 0.34, 0.33, 0.32

Mode selection: click to enter tapping mode or screwing mode.

Restore settings: click and select "OK" to restore all settings to the factory default values. Be careful!


Lock axis normally open/auto lock axis: click to switch different modes

Shaft locking is normally open: the shaft will not be locked after the motor stops running.

Automatic shaft locking: after the motor stops running, it will continuously maintain the torque output to the time set in "Torque holding time".

Machine parameters: the underlying parameters of the machine are set incorrectly, which will affect the stability of the machine. If you need a password, please contact our company.

Factory parameters: the factory parameters of the machine are set. If the settings are incorrect, the machine will fail. If you need a password, please contact our company.



Injection Setting * (optional injection or injection components have this function)

Click "User parameter", and click "Injection setting" on the right to enter the setting interface above.


Automatic tapping: in the automatic tapping mode, click the button to switch the injection mode.

Manual tapping: In the manual tapping mode, click the button to switch the injection mode.

Injection time: enter a value in the box to control the time of each injection. The input range is 0.1 -9.0 seconds.

Jet setting *: Click to enter the jet setting interface. This button is only available with the optional "Air Jet - Component".

Test fuel injection: click to test whether the fuel injection circuit is normal. Click this button when adjusting the fuel injection/gas volume.



Jet Setting * (this function is only available with the optional jet single component)

In the "fuel injection setting", click "fuel injection setting" in the lower right corner to enter the setting interface above.

Automatic tapping: in the automatic tapping mode, click the button to switch the air jet mode.

Manual tapping: In the manual tapping mode, click the button to switch the air jet mode.

Injection time: enter a value in the box to control the time of each injection. The input range is 0.1 -9.0 seconds.


Injection setting: click to return to the injection setting interface.

Test air jet: click to test whether the air jet path is normal. Click this button when adjusting the air injection volume.

Common Fault Codes

Code	Analysis	Method
E-001	Over current	Check tap head perpendicularity, if driver and motor normal, if tap seized
E-002	Over voltage	Voltage overtension
E-004	Over current	Current persistent anomaly
E-008	encoder abnormal	Check Encoder line connection
E-010	overrun	Check UVW Test if ok, forward speed, motor and encoder connect
E-037	Encoder Error	Find signal interference and far away
E-150	communication checkout	Check Encoder line connection
E-200	Servo communication timeout	Check line and Encoder line connection
E-220	Password error	Retry with password, or contact with us
E-312	Torque protection error	Close Torque protection or increase value

Adjusting Tap Holder Torque Setting



The torque adapters are factory preset near the standard break torque limits developed for each tap size. When the tap reaches the bottom of the hole, resistance will cause the torque holder's safety clutch to ratchet and stop the tap from turning, over-torquing and ultimately breaking.

When tap hardened steel, an increase in the factory torque settings may be required. When tap soft materials or plastics, a decrease in factory torque setting prevents the tap from over-torquing.


There are two lock positions on the outside diameter of the adapter designed to hold the tail of the snap ring. These two positions permit an adjustment range from one-half to a full notch on the threaded ring. The tail of the snap ring must be inserted in the hole at either position and through a notch on the thread ring in order to lock in the adjusted torque setting.

CAUTION: Never adjust the torque setting more than one notch at a time.


Standard Tap Dimensions

ISO			JIS			DIN		
Tap measure	Norm		Tap measure	Norm		Tap measure	Norm	
Dia× Square	ISO529 ⁽¹⁾	ISO529 ISO2283 ⁽²⁾	Dia× Square	JISB4430 ⁽²⁾	Inches	Dia× Square	DIN371 ⁽⁴⁾	DIN374 DIN376 ⁽³⁾
2.24×1.80		M3.0	3.00×2.50	M1.0-M2.6		2.50×2.10	M1-M1.8	M3.5
2.50×2.00	M1.0-M2.0	M3.5	4.00×3.15		UNC 1/8"	2.80×2.10	M2-M2.5	M4.0
2.80×2.24	M2.2-M2.6		4.00×3.20	M3.0-M3.5	#5-#6	3.50×2.70	M3	M4.5-M5.0
3.15×2.50	M3.0	M4.0	5.00×4.00	M4.0-M4.5	#8	4.00×3.00	M3.5	
3.55×2.80	M3.5	M4.5	5.00×4.00		UNC 5/32"	4.50×3.40	M4.0	M6.0
4.00×3.15	M4.0	M5.0	5.50×4.50	M5.0-M5.5	#10	5.50×4.30		M7.0
4.50×3.55	M4.5	M6.0	5.50×4.50		UNC 3/16"	6.00×4.90	M4.5-M6	M8.0
5.00×4.00	M5.0		6.00×4.50	M6.0	UNC 1/4"	7.00×5.50	M7.0	M10
5.60×4.50		M7.0	6.10×5.00		UNC 5/16"	8.00×6.20	M8.0	
6.30×5.00	M6.0	M8.0	6.20×5.00	M7.0-M8.0		9.00×7.00		M12
7.10×5.60	M7.0	M9.0	7.00×5.50	M9.0-M10	UNC 3/8"	10.00×8.00		M14
8.00×6.30	M8.0	M10-M11	8.00×6.00	M11	UNC 7/16"	11.00×9.00		M16
9.00×7.10	M9.0	M12	8.00×6.00	M12	PT 1/8"	12.00×9.00		M18
10.00×8.00	M10		8.50×6.50			14.00×11.00		M20
11.20×9.00		M13-M15	9.00×7.00		UNC 1/2"	16.00×12.00		M22-M26
12.50×10.00		M16-M17	10.50×8.00	M14-M15	UNC 9/16"	18.00×14.50		M27
14.00×11.20		M18-M21	11.00×9.00		PT 1/4"	20.00×16.00		M29-M32
16.00×12.50		M22-M23	12.00×9.00		UNC 5/8"	22.00×18.00		M33
18.00×14.00		M24-M26	12.50×10.00	M16		25.00×20.00		M34-M38
20.00×16.00		M27-M30	14.00×11.00	M18	PT 3/8"	28.00×22.00		M39-M42
22.40×18.00		M31-M33	14.00×11.00		UNC 3/4"	32.00×24.00		M44-M50
25.00×20.00		M36	15.00×12.00	M20		36.00×29.00		M52
28.00×22.40		M37-M42	17.00×13.00	M22	UNC 7/8"	40.00×32.00		M55-M60
31.50×25.00		M44-M50	18.00×14.00		PT 1/2"	45.00×35.00		
35.50×28.00		M52-M56	19.00×15.00	M24-M25				
40.00×31.50		M58-M65	20.00×15.00	M26-M27	UNC 1"			
45.00×35.50		M66-M75	21.00×17.00	M28				
			22.00×17.00		UNC 1 1/8"			
			23.00×17.00	M30	PT 3/4"			
			24.00×19.00	M32	UNC 1 1/4"			
			25.00×19.00	M33				
			26.00×21.00	M34-M35	UNC 1 3/8"			
			26.00×21.00		PT 1"			
			28.00×21.00	M36	PT 1 1/4"			
			30.00×23.00	M39				
			32.00×25.00	M42				
			35.00×26.00		PT 1 3/8"			
			38.00×29.00		PT 1 1/2"			

Servo Electric Tapping Machine Exploded views



The following components marked with "*" are not included in the standard configuration. If necessary, please contact our company for additional options.



WARRANTY CARD

Thank you for purchasing our products!

The design and process of this product comply with relevant quality standards. According to the national Three Guarantees, if this product has non-human faults within one year from the date of purchase, we will provide free warranty services for cardholder users according to the warranty regulations.

1. Product warranty data filling:

User name: _____ Tel: _____

Add: _____

Product Name		Fuselage Model		Dealer Stamp
Dealer Name		Telephone		
Dealer Address		Zip Code		
Invoice No		Purchase Date		

2. Product maintenance record

Fault Display		Replace Material	
Repair Mode		Repair Date	
Repair Unit		Warranty	Yes <input type="checkbox"/> No <input type="checkbox"/>
Remarks			

*This warranty card must be provided when receiving service.
Please keep it properly!

Product certificate

MODEL M16E M30E M36E

NUMBER _____

DATE _____

TEST _____